




U imp 6 kV


Ie 20 A

Iq 3 kA

Max. zul. Motorleistung / Max. Motor Performance / Max. Potencia admisible del Motor / Puissance max. du Moteur / Pot. max. ammissibile dei motori




	EN 60947 – 4 - 1
50.. ..60 Hz	1~
120 V AC3	2 kW
250 V AC3	4 kW




DRAUFSICHT / TOP VIEW / VISTA SUPERIOR / VUE SUPERIEURE / VISTA DALL'ALTO
SCHALTBILD / WIRING DIAGRAM / ESQUEMA DE CONEXION / SCHEMA DE RACCORDAMENTO / SCHEMA ELETTRICO

Druckdifferenz optional
Pressure differential optional
Diferencial de presión opcional
Différentiel de pression optionelle
Pressione differenziale opzionale



Motor
Moteur
Motore

Netz
Mains
Red
Alimentation
Alimentazione




Einschaltdruck
Cut-in pressure
Presión de disparo inferior
Pression de d'enclenchement
Pressione di attacco

1.8 Nm
Drehmoment
Tightening torque
Par de giro
Couple
Momento torcente

Motor
Moteur
Motore

Netz
Mains
Red
Alimentation
Alimentazione

DRUCKDIAGRAMME / PRESSURE DIAGRAMS / DIAGRAMAS DE REGULACION / DIAGRAMMES DE REGLAGE / DIAGRAMMI TARATURE



Einschaltdruck
Cut-in pressure
Presión de disparo inferior
Pression de d'enclenchement
Pressione di attacco

Ausschaltdruck p_o (bar)
Cut-out pressure
Presión de disparo superior
Pression déclenchement
Pressione di distacco

Einbau und Anschluß nur durch Fachkraft; nach Anbringung von Zubehör Funktionsüberprüfung durch Elektrofachkraft erforderlich

Installation and assembly of electrical equipment shall be carried out by qualified personnel only
 Instalación y ensamblaje de equipos eléctricos deberán ser efectuados solamente por personal cualificado

L'installation et raccordement des appareils doit être effectué par du personnel qualifié

L'installazione e l'assemblaggio delle parti elettriche vanno eseguite esclusivamente da personale qualificato

APPROBATIONEN / APPROVALS / APROBACIONES / APPROBATIONS / APPROVAZIONI



100% Einschaltdauer (uninterrupted duty)

Kurzschlußeinrichtung / Short-circuit protection / Protección contra corto circuito


Protection contre court-circuit/ Protezione contro corto circuito

Type	Koordination Type " 1 "		Koordination Type " 2 "	
Tipo	Co-ordination Type " 1 "		Co-ordination Type " 2 "	
	Coordinación Tipo " 1 "		Coordinación Tipo " 2 "	
	Coordination Type " 1 "		Coordination Type " 2 "	
	Coordinamento Tipo " 1 "		Coordinamento Tipo " 2 "	
Sicherung gL	manuell	pneumatisch	manuell	pneumatisch
Fuse (slow)			35A	50A
Fusible (retardado)				
Fusible (retardé)				
Fusibile (ritardato)				

Schutz / Degree of Protection / Grado de Protección / Degré de Protection / Grado di Protezione

IP 44

Einbaulage berücksichtigen / Mounting position must be observed / Respetar posición de montaje
 Observer position de montage / Rispettare posizione montaggio



0.0800.0343 02.11.2005



Condor Pressure Control GmbH

Warendorfer Straße 47 – 51
 D-59320 Ennigerloh

Telefon: +49 (0) 25 87 / 89 – 0
 Telefax: +49 (0) 25 87 / 89 - 140

info@condor-cpc.com
 www.condor-cpc.com